



# Grove RT890E

## Product Guide



### **Features**

- 80 t (90 USt) capacity
- 11,4 m 43,2 m (38 ft 142 ft) five-section, full power boom
- 10 m 17 m (33 ft 56 ft) offsettable bi-fold lattice, swingaway extension
- 4,8 m (16 ft) or 9,7 m (32 ft) extension inserts
- Grove MEGAFORM™ boom
- 9979 kg (22,000 lb) counterweight hydraulically installed and removed



# Features

### Removable counterweight

Counterweight and auxiliary hoist is hydraulically removed/installed for easier hauling from job to job.





### Power luffing extension

For improved up-and-over reach, a power luffing extension is available on the RT890E and hydraulically offsets from the super-structure cab from  $5^{\circ}$  to  $40^{\circ}$ .



The Full Vision cab on the RT890E tilts up to 20° providing the operator additional comfort when working at long boom and extension lengths.



CraneSTAR is an exclusive and innovative crane asset management system that helps improve your profitability and reduce costs by remotely monitoring critical crane data. Visit www.cranestar.com for more information.



### Boom

The RT890E is equipped with a 11,4 m - 43,2 m (38 ft - 142 ft) five-section, full power boom. The Grove MEGAFORM<sup>™</sup> boom shape eliminates weight and increases capacity compared to conventional shapes.

R

# Contents


2
4
7
8
9
10
11
12
13
14
15
17
21

# Specifications

### Superstructure



11,4 m - 43,2 m (38 ft - 142 ft) five-section, sequenced synchronized full power boom with A and B mode. Maximum tip height: 45,7 m (150 ft).



 $10\ m-17\ m$  (33 ft – 56 ft) offsettable bi-fold lattice swingaway extension. Offsets 0°, 20° and 40°. Stows alongside base boom section.

Maximum tip height: 62,7 m (206 ft).

### \*Optional lattice extension

 $10\ m-17\ m$  (33 ft – 56 ft) hydraulically offsettable bi-fold lattice swingaway extension. Offsets from 0° to 40°. Stows alongside base boom section.

Maximum tip height: 62,7 m (206 ft).



(2) x 4,8 m (16 ft) lattice extension inserts. Installs between the boom nose and bi-fold extension, non-stowable.

Maximum tip height: 72,5 m (238 ft)

### 🔋 🔹 Boom nose

Five nylatron sheaves mounted on heavy duty tapered roller bearings with removable pin-type rope guards. Quick reeving type boom nose. Removable auxiliary boom nose with removable pin type rope guard.



### **Boom elevation**

One double acting hydraulic cylinder with integral holding valve provides elevation from -3° to +78°.



### Load moment and anti-two block system

Standard "Graphic Display" load moment and anti-two block system with audio-visual warning and control lever lockout. These systems provide electronic display of boom angle, length, radius, tip height, relative load moment, maximum permissible load, load indication and warning of impending two-block condition. The standard Work Area Definition System allows the operator to pre-select and define safe working areas. If the crane approaches the pre-set limits, audio-visual warnings aid the operator in avoiding job-site obstructions.



20° tilt, Full-vision, all-steel fabricated with acoustical lining and tinted safety glass throughout. Deluxe seat incorporates armrest-mounted hydraulic single-axis controllers. Tilt/telescoping steering wheel with various controls incorporated into the steering column. Other standard features include:, hot water heater, cab circulating air fan, sliding side and rear windows, sliding skylight with electric wiper and sunscreen, electric windshield wash/wipe, fire extinguisher, seat belt, air conditioning, and dual cab mounted work lights.

# Swing

Two speed, planetary swing drive with foot applied multi-disc wet brake. Spring applied, hydraulically released swing brake. Single position mechanical house lock, operated from cab. Maximum speed: 2.0 rpm.

### Counterweight

9979 kg (22,000 lb). Hydraulically installed and removed.

# **Specifications**

### Superstructure (continued)

#### Hoist specifications (HP30-19G) main and auxiliary hoist

Planetary reduction with automatic spring applied multi-disc wet brake. Electronic hoist drum rotation indicators, and hoist drum cable followers.

Maximum single line pull:

1st layer: 9185 kg (20,250 lb) 3rd layer: 7715 kg (17,010 lb) 5th layer: 6650 kg (14,660 lb)

Maximum permissible line pull: 7620 kg (16,800 lb) with 6x37 class rope 7620 kg (16,800 lb) with 35x7 class rope

Maximum single line speed: 156 m/min (514 fpm)

Rope construction: 6x36 EIPS IWRC, special flexible 35x7 Flex-X, rotation resistant

Rope diameter: 19 mm (3/4 in)

Rope length:

Main hoist: 182 m (600 ft)

Auxiliary hoist: 182 m (600 ft)

Maximum rope stowage: 256 m (841 ft)

### Carrier

### Chassis

Box section frame fabricated from high-strength, low alloy steel. Front/rear towing and tie down lugs.

### Outrigger system

Four hydraulic telescoping single-stage double box beam outriggers with inverted jacks and integral holding valves. Three position setting, 0%, 50% and fully extended. Outrigger monitoring comes standard.

All steel fabricated, quick release type outrigger floats, 775 mm (30.5 in) diameter.

Maximum outrigger pad load: 56 700 kg (125,000 lb).

### Hydraulic system

Two main pumps ([1] piston and [1] gear) with a combined capacity of 503 LPM (133 GPM).

Maximum operating pressure: 277.7 bar (4000 psi).

Three section pressure compensated valve bank. Return line type filter with full flow by-pass protection and service indicator. Replaceable cartridge with micron filtration rating of 5/12/16. 959 L (253 gallon) hyd. reservoir. Carrier mounted oil cooler with thermostatically controlled hydraulic motor driven fan/air to oil. System pressure test ports.

## **Outrigger controls**

Controls and crane level indicator located in cab.



### Engine (Tier IV)

Cummins QSB 6.7L diesel, six-cylinder, turbo-charged. 205 kW (275 hp) at 2500 rpm.

Meets emissions per U.S. E.P.A., Tier IV and E.U. Stage III B.

Maximum torque: 992 Nm (732 ft/lb) at 1500 rpm.

Fuel requirement: Minimum of 15 ppm sulphur content (Ultra Low Sulphur Diesel Fuel)

Note: Tier IV engine required in North American and European Union countries.



### Engine (Tier III)


Cummins QSB 6.7 L diesel, six cylinders, turbo-charged, 205 kW (275 bhp) (Gross) at 2500 rpm.

Maximum torque: 987 Nm (728 ft/lb) at 1500 rpm.

Note: Required for sale outside of North American and European Union countries.

### **Fuel tank capacity**

280 L (74 gal)



Full rangeshift with 6 forward and 6 reverse speeds. Front axle disconnect for 4 x 2 travel.


## Electrical system

Three 12 V - maintenance free batteries.

12 V starting and lighting. Battery disconnect. CanBus Diagnostic system.

## RELIABLE CRANE SERVICE

# Specifications





4 x 4.



Fully independent power steering:

Front: Full hydraulic steering wheel controlled.

Rear: Full hydraulic switch controlled.

Provides infinite variations of 4 main steering modes: front only, rear only, crab and coordinated.

Rear steer indicator.

Turning radius: 7,3 m (24 ft)

### Axles

Front: Drive/steer with differential and planetary reduction hubs rigid mounted to frame.

Rear: Drive/steer with differential and planetary reduction hubs pivot mounted to frame.

### --- Oscillation lockouts

Automatic full hydraulic lockouts on rear axle permits 25,4 cm (10 in) oscillation only with boom centered over the front.

## O Brakes


Full hydraulic split circuit operating on all wheels. Spring-applied, hydraulically released parking brake mounted on front axle.

### () Tires

Standard 29.5 x 25 - 34 bias ply, Titan

### **Lights**

Full lighting including turn indicators, head, tail, brake and hazard warning lights.



35 km/h (22 mph)



### 75%

(Based on 52 607 kg [115,976 lb] GVW, 29.5 x 25 tires, 43,2 m [142 ft] boom, plus 17,0 m [56 ft] swingaway, 22,000 lb counterweight, 80 t [90 USt] hookblock and 9,1 t [10 USt] headache ball).


### Miscellaneous standard equipment

Full width steel fenders, full length aluminum decking, dual rear view mirrors, hook-block tie down, electronic back-up alarm, light package, front stowage well, cab air conditioning, tachometer/hourmeter, rear wheel position indicator, 36,000 BTU hot water cab heater, hoist mirrors, engine distress A/V warning system, front/rear tie down and tow lugs, coolant sight level indicator, CraneSTAR asset management system.

### \*Optional equipment

- Auxiliary Lighting and Convenience Package: includes cab mounted amber flashing light, dual base boom mounted floodlights. LMI light bar (in cab), and rubber mat for stowage trough
- 360° NYC style mechanical swing lock
- Rear Pintle hook
- Cab controlled cross axle differential locks, (front and rear)
- PAT event recorder
- 3rd wrap indicator for main and/or auxiliary hoists
- Wind speed indicator (wireless).
- C.E. Mark Conformance
- Value Package: Includes 33 ft 56 ft manual bi-fold swingaway, 360° swing lock, and auxiliary hoist package
- Auxiliary Hoist Package: Includes HP30-19G auxiliary hoist with rotation indicator, cable follower, auxiliary hoist mirror and 185 m (607 ft) of non-rotational wire rope.

# **Dimensions and weights**



Dimensions are in mm (inches)


Weights			
	G.V.W.	Front	Rear
	kg (lb)	kg ( lb)	kg (lb)
<b>Basic Machine</b> including 43,3 m (142 ft) main boom, main and aux. hoist with 182,8 m (600 ft) of rope, manual offsettable bifold swingaway, full counterweight, 9,1 t (10 USt) headache ball, and 80 t (90 USt) hookblock:	53 178	25 915	27 263
	(117,235)	(57,131)	(60,104)
Substitute: Hydraulic offsettable bifold swing-away	53 496	26 394	27 103
	(117,937)	(58,187)	(59,750 <b>)</b>
<b>Remove:</b> Counterweight and aux. hoist (manual offsettable S/A)	43 250	30 657	12 592
	(95,348)	(67,587)	(27,761)
Remove: Counterweight and aux. hoist Hyd. offsettable S/A)	43 407	30 930	12 477
	(95,695)	(68,188)	(27,507)
Remove: Counterweight, aux. hoist, and either extension	42 227	27 696	13 171
	(93,094)	(64,058)	(29,036)

Grove RT890E


# Working range

N N

### 141.7 ft main boom 32 ft - 56 ft fixed offset swingaway



Operating radius in feet from axis of rotation



Dimensions are for largest Grove furnished hook block and headache ball, with anti-two block activated.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

**N** 

# Mode A vs. Mode B

Mode A – inner-mid retracted									
		Main boom length in feet							
	37.3	50.4	63.4	76.4	89.4	102.4	115.4	141.7	
Boom section	Boom sections: Percent extension								
Inner-mid	0	0	0	0	0	0	0	100	
Center-mid	0	50	100	100	100	100	100	100	
Outer-mid	0	0	0	25	50	75	100	100	
Fly	0	0	0	25	50	75	100	100	

			Mode I	B – norma	al mode				
	Main boom length in feet								
	37.3	50.5	63.7	76.7	89.8	102.8	115.8	128.8	141.7
Boom sections	Boom sections: Percent extension								
Inner-mid	0	50	75	75	100	100	100	100	100
Center-mid	0	0	25	75	100	100	100	100	100
Outer-mid	0	0	0	0	0	25	50	75	100
Fly	0	0	0	0	0	25	50	75	100

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

## Load charts (Mode B)

1

37.3 ft - 141	.7 ft 22,00		00% spread	<b>Q</b> 360°					
			•		Pounds				
Feet	37.3	50.5	63.7	Main bo 76.7	om length in 89.8	feet 102.8	115.8	128.8	141.7
10	180,000	134,000	*97,500	/0./	03.0	102.0	115.8	120.0	141.7
12	(68.5) 156,000	(75) 134,000	(78) 97,500 (76 F)						
15	(65) 128,500	(72.5) 127,500	(76.5) 97,500	69,950	*46,600				
20	(59.5) 98,650 (40.5)	(69) 97,600 (62 5)	(74) 86,200	(77) 63,600 (73)	(78) 46,600 (76 F)	*38,700			
25	(49.5) 78,800	(62.5) 77,800 (55.5)	(69) 74,850	(73) 55,100	(76.5) 41,950	(78) 38,700 (75 5)	*37,900	*30,850	
30	(36.5) 51,550 (12.5)	58,700	(64) 59,300 (58,5)	(69) 48,150 (65)	(73) 37,350 (69.5)	(75.5) 37,900 (72.5)	(78) 35,000	(78) 30,850 (77 5)	*24,400
35	(12.5)	(47.5) 43,250 (38.5)	(58.5) 43,200 (52.5)	(65) 42,450 (60.5)	33,300 (66)	33,200 (69.5)	(75) 30,950 (72.5)	(77.5) 28,900 (75)	(78) 24,400
40		33,250 (26)	32,850 (46.5)	33,050 (56)	29,850 (62.5)	29,300 (66.5)	27,450 (70)	25,850 (72.5)	(77) 24,250 (75)
45		(20)	25,650 (39)	26,000 (51)	25,900 (58.5)	25,950 (63.5)	24,450 (67)	23,150 (70)	21,900 (73)
50			20,350 (30.5)	20,750 (45.5)	20,550 (54.5)	21,950 (60)	21,800 (64.5)	20,750 (67.5)	19,800 (70.5)
55			16,200 (16.5)	16,800 (39.5)	16,450 (50)	17,800 (56.5)	19,150 (61.5)	18,650 (65)	17,900 (68.5)
60			(10.5)	13,600 (33)	13,200 (45.5)	14,550 (53)	15,900 (58.5)	16,800 (62.5)	16,150 (66)
65				11,000	10,600 (40,5)	11,900 (49)	13,250 (55.5)	14,200	14,650 (64)
70				(23.3)	8420 (34.5)	9750 (45)	11,050 (52)	11,950 (57)	12,850 (61.5)
75					6570 (28)	7910 (40.5)	9250 (48.5)	10,100 (54.5)	10,950 (59)
80					4960 (18)	6340 (36)	7670 (45)	8530 (51.5)	9380 (56.5)
85						4990 (30)	6320 (41)	7150 (48.5)	7980 (54)
90						3780 (23)	5140 (37)	5950 (45)	6770 (51)
95						2710 (10)	4100 (32)	4900 (41.5)	5700 (48.5)
100							3160 (26)	3960 (37.5)	4750 (45.5)
105							2310 (18.5)	3130 (33.5)	3910 (42)
110								2370 (28.5)	3150 (38.5)
115								1680 (22.5)	2460 (35)
120								1050 (13)	1840 (30.5)
125									1250 (25.5)
	om angle (deg)							0	24
#LMI operati *This capacit	om length (ft) a ng code. Refer t y is based upon mangles are in c	o LMI manual fo maximum obta	or instructions.	ngle.				128	5.ð

		L	ifting capacitie:	s at zero degre	e boom angle				
Boom Main boom length in feet									
angle	37.3	50.5	63.7	76.7	89.8	102.8	115.8		
0°	27,500 (30.1)	15,950 (43.3)	9560 (56.4)	5840 (69.5)	2730 (82.6)	1910 (95.6)	1200 (108.5)		
Note: ( ) Refe	ote: () Reference radii in feet. A6-829-103321A								

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

## **Load charts** Bi-fold swingaway (fixed offsettable angles)

37.3 ft - 141.7 ft	33 ft -	56 ft	22,000		100% ft spread	<b>Q</b> 360°
			Pour	nds		
		33 ft LENGTH	I		56 ft LENGTH	1
Feet	0° OFFSET #0021	20° OFFSET #0022	40° OFFSET #0023	0° OFFSET #0041	20° OFFSET #0042	40° OFFSET #0043
40	13,700 (78)					
45	13,700 (76.5)	°13,000 (78)		7160 (78)		
50	13,700 (75)	12,950 (77.5)		7160 (77.5)		
55	13,700 (73)	12,600 (76)	*10,250 (78)	7160 (76)		
60	13,700 (71.5)	12,200 (74)	10,050 (77)	7160 (74.5)	*6400 (78)	
65	13,700 (69.5)	11,900 (72.5)	9900 (75)	7160 (73)	6250 (77.5)	
70	13,500 (68)	11,550 (70.5)	9750 (73)	7160 (71.5)	6110 (76)	
75	12,400	11,250 (68.5)	9610 (71)	7160 (70)	5980 (74.5)	°5110 (78)
80	10,800 (64)	11,000 (67)	9480 (69)	7160 (68.5)	5850 (73)	5020 (77)
85	9330 (62)	10,250 (65)	9370 (67)	7150 (66.5)	5730 (71.5)	4930 (75)
90	8050 (60)	8900	8980 (65)	6960	5620 (69.5)	4850
95	6920	(63) 7700 (C1)	8530	(65) 6770 (63 5)	5510	(73.5) 4780 (71.5)
100	(58) 5920	(61) 6630 (50)	(63) 7360	(63.5) 6590	(68) 5410	(71.5) 4710 (60.5)
105	(56) 5030	(59) 5690	(61) 6310	(61.5) 6030	(66) 5310	(69.5) 4650
110	(54) 4230	(56.5) 4830 (54.5)	(58.5) 5370	(60) 5200	(64.5) 5220	(68) 4600
115	(52) 3510	(54.5) 4060	(56.5) 4520	(58)	(62.5) 5110	(66) 4550
120	(49.5) 2850	(52)	(54) 3750	(56.5)	(60.5) 4780	(64) 4500
125	(47.5) 2250	(50) 2730	(51.5) 3040	(54.5) 3150	(59) 4080	(62) 4460
130	(45) 1700	(47.5) 2150	(49) 2400	(52.5) 2580	(57) 3450	(60) 3970
135	(42) 1200	(44.5) 1610	(46)	(50.5) 2060	(55) 2870	(58) 3330
140	(39.5)	(42) 1120		(48.5) 1570	(53) 2330	(55.5) 2730
		(39)		(46.5) 1130	(50.5) 1830	(53) 2180
145				(44)	(48.5) 1370	(50.5) 1670
150					(46)	(48)
155 Minimum boom angle						(45)
(°) for indicated length (no load)	38	38	40	43	44	44
Maximum boom length (ft) at 0° boom angle (no load) NOTE: () Boom angles ar	re in degrees	102.8			89.8	-829-103447

#LMI operating code. Refer to LMI manual for operating instructions.

\*This capacity is based upon maximum boom angle.

### NOTES:

- 1. All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- The 33 ft extension length may be used with single or double part line lifting service. The 56 ft extension length may be used for single line lifting service only.
- 3. For main boom lengths less than 141.7 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use rating of the next lower boom angle.
- 4. WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- 6. Capacities listed are with outriggers properly extended and vertical jacks set only.
- 7. When lifting over the main boom nose with 33 ft or 56 ft extension erected, the outriggers must be fully extended or 50% extended (17.3 ft spread).


THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

Grove RT890E The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.


# Working range

3

### 141.7 ft main boom and one 16 ft insert



Operating radius in feet from axis of rotation




Dimensions are for largest Grove furnished hook block and headache ball, with anti-two block activated.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

# Working range

### 141.7 ft main boom and two 16 ft inserts



Operating radius in feet from axis of rotation



Dimensions are for largest Grove furnished hook block and headache ball, with anti-two block activated.

Grove RT890E

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

## Load charts Bi-fold swingaway with inserts (fixed angles)

<b>37.3 ft - 141.7 ft</b>	= 33 ft - 5		or 2 16 ft inserts	22,000 lt	24 ft spi				
	Pounds								
	0°	20°	1 INSERT)	0°	20°	40°			
Feet	#0064	OFFSET #0065	#0066	OFFSET #0084	OFFSET #0085	#0086			
50	6300 (78)								
55	6300 (77.5)								
60	6300 (76.5)			5000 (78)					
65	6300 (75)			5000 (77.5)					
70	6300 (73.5)	*6100 (78)		5000 (76)					
75	6,00 (72)	5860 (77.5)		5000 (74.5)	*4900 (78)				
80	6300 (70.5)	5750 (76)	*5000 (78)	5000 (73.5)	4900 (77.5)				
85	6300 (69)	5650 (74.5)	4890 (77.5)	5000 (72)	4900 (76)				
90	6300 (67.5)	5550 (73)	4820 (76)	4900 (70.5)	4900 (74.5)	*4800 (78)			
95	6300 (66)	5450 (71.5)	4760 (74.5)	4850 (69.5)	4900 (73.5)	4640 (76.5)			
100	6300 (64.5)	5360 (70)	4690 (73)	4800 (68)	4710 (72)	4370 (75)			
105	5810 (63)	5120 (68)	4580 (71.5)	4670 (66.5)	4420 (70.5)	4120 (73.5)			
110	5030 (61.5)	4880 (66.5)	4480 (69.5)	4550 (65)	4130 (69)	3870 (72)			
115	4320 (59.5)	4620 (65)	4270 (68)	4240 (63.5)	3880 (67.5)	3650 (70.5)			
120	3680 (58)	4370 (63.5)	4060 (66)	3850 (62)	3630 (66)	3440 (69)			
125	3100 (56.5)	4110 (61.5)	3870 (64.5)	3260 (60.5)	3410 (64.5)	3240 (67.5)			
130	2560 (54.5)	3500 (60)	3680 (62.5)	2720 (59)	3190 (63)	3050 (65.5)			
135	2070 (53)	2940 (58)	3510 (60.5)	2220 (57.5)	3000 (61.5)	2880 (64)			
140	1610 (51)	2420 (56)	2980 (58.5)	1760 (56)	2630 (60)	2710 (62.5)			
145	1190 (49)	1950 (54.5)	2440 (56.5)	1340 (54.5)	2,150 (58)	2560 (60.5)			
150		1500 (52.5)	1930 (54.5)		1700 (56.5)	2210 (58.5)			
155		1090 (50.5)	1470		1290 (54.5)	1750 (57)			
160		()	1030 (50)		(	1310 (55)			
Minimum boo (°) for indicated length (no load	d 48 d)	49	49	52		53			
Maximum boo (ft) at 0° boom (no load)		76.7			76.7				

NOTE: ( ) Boom angles are in degrees. A6-829-103478 #LMI operating code. Refer to LMI manual for operating instructions. \*This capacity is based upon maximum boom angle.

#### NOTES:

- All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- 2. The 56 ft extension length may be used for single line lifting service only.
- 3. For main boom lengths less than 141.7 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use rating of the next lower boom angle.
- WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- 5. Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- When lifting over the main boom nose with 56 ft extension erected and inserts, the outriggers must be fully extended and vertical jacks set.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

## Load charts (Mode A)

			Q					
37.3 ft - 141.7 f	t 22,000 lb	100% 24 ft spre	360° ad					
				Po	ounds			
Feet	37.3	50.4	63.4	76.4	89.4	102.4	115.4	141.7
10	180,000 (68.5)	134,000 (75)	*80,800 (78)					
12	156,000 (65)	134,000 (72.5)	80,800 (76.5)	*38,700 (78)				
15	128,500 (59.5)	129,000 (68.5)	80,800 (73.5)	38,700 (77)	*38,500 (78)			
20	98,650 (49.5)	98,950 (62)	70,950 (68.5)	38,700 (73)	38,500 (76.5)	*38,400 (78)		
25	78,800 (36.5)	79,150 (55)	62,300 (63.5)	38,700 (69)	38,500 (73)	38,400 (76)	24,400 (78)	
30	51,550 (12.5)	60,500 (47)	55,250 (58)	38,700 (65)	38,500 (69.5)	37,500 (73)	24,400 (76)	*24,400 (78)
35		45,150 (38)	44,900 (52.5)	38,700 (60.5)	36,750 (66)	33,150 (70)	24,400 (73.5)	24,400 (77)
40		35,250 (25.5)	34,700 (46)	36,750 (56)	32,750 (62)	29,550 (67)	24,400 (70.5)	24,250 (75)
45		()	27,600 (39)	29,450 (51)	29,400 (58.5)	26,500 (63.5)	24,400 (68)	21,900 (73)
50			22,400 (30)	24,000 (45.5)	25,650 (54.5)	23,950 (60.5)	22,050 (65)	19,800 (70.5)
55			18,250 (15.5)	19,850 (39.5)	21,350 (50)	21,750 (57)	20,000 (62)	17,900 (68.5)
60			()	16,600 (32.5)	17,950 (45.5)	18,900 (53.5)	18,250 (59)	16,150 (66)
65				13,850 (23)	15,200 (40)	16,150 (49.5)	16,700 (56)	14,650 (64)
70					12,950 (34.5)	13,850 (45.5)	14,800 (53)	12,850 (61.5)
75					11,000 (27.5)	11,950 (41)	12,900 (49.5)	10,950 (59)
80					9340 (17)	10,300 (36)	11,250 (45.5)	9380 (56.5)
85					(17)	8900 (30)	9830 (42)	7980 (54)
90						7640 (22.5)	8590 (37.5)	6770 (51)
95						6520 (8)	7510 (32.5)	5700 (48.5)
100						(-/	6520 (26.5)	4750 (45.5)
105							5640 (18.5)	3910 (42)
110							(10.5)	3150 (38.5)
115								2460 (35)
120								1840 (30.5)
125								1250 (25.5)
Minimum boom Maximum boom #LMI operating c *This capacity is Note: () Boom a	length (ft) at 0 de ode. Refer to LM based upon maxi	eg boom angle ( I manual for ins imum obtainab	(no load) tructions.					24 115.4
Room		Lifting ca	pacities at zero de Ma	egree boom ang ain boom lengt				
Boom angle	37.3	50.4	63.4	76.4	89.4	102.4	115.4	
0°	27,500 (30.1)	17,300 (43.2)	11,050 (56.2)	8580 (69.2)	6700 (82.2)	5380 (95.2)	4280 (108.2)	_

Note: ( ) Reference radii in feet.

6-829-103320A

Grove RT890E

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

## Load charts (Mode A)

7.3 ft - 76.4 f	t 22,00	DO IB	Stationary	360°	37.3 ft - 76.4 f	t 22,00		k and carry to 2.5 mph	Boom centere over front
			Pounds					Pounds	
		Main	boom					in boom	-
Θ		Main boon	n length in fee	:	G		Main boo	m length in fo	eet
Feet	37.3	50.4	63.4	- 76.4	Feet	37.3	50.4	63.4	76.4
12	39,500 (65)	41,650 (72.5)			12	41,600 (65)	41,700 (72.5)		
15	37,750 (59.5)	38,950 (68.5)	18,900 (73.5)	15,650 (77)	15	41,600 (59.5)	41,700 (68.5)	22,400 (73.5)	15,650 (77)
20	24,850 (49.5)	24,850 (62)	18,900 (68.5)	15,650 (73)	20	36,250 (49.5)	36,450 (62)	22,400 (68.5)	15,650 (73)
25	16,300 (36.5)	16,650 (55)	17,450 (63.5)	15,650 (69)	25	27,600 (36.5)	28,250 (55)	22,400 (63.5)	15,650 (69)
30	10,200 (12.5)	11,350 (47)	11,450 (58)	13,200 (65)	30	21,300 (12.5)	22,200 (47)	22,400 (58)	15,650 (65)
35		7650 (38)	7630 (52.5)	9280 (60.5)	35		17,500 (38)	17,950 (52.5)	15,650 (60.5)
40		4920 (25.5)	5020 (46)	6510 (56)	40		13,800 (25.5)	14,350 (46)	15,650 (56)
45				4490 (51)	45			11,000 (39)	12,500 (51)
indicated	boom angle ( I length (no lo	bad)	39	46	50			8360 (30)	9820 (45.5)
Maximum bo boom a	om length (f angle (no loa	t) at 0° d)	50	.4	55			6240 (15.5)	7690 (39.5)
Lif			gree boom angl	e	Minimum bo	om angle (°)	for indicated load)	ength	36
Boom angle	37.3	Aain boom lei 50.4	ngth in feet		Maximum bo	om length (	ft) at 0° boom oad)	angle	63.4
0°	10,050 (30.1)	3150 (43.2)			Lifting ca	• •	ero degree boo	om angle	
OTE: () Refere	ence radii in f	eet.	A Il for instruction	6-829-103452A s.	Boom angle	37.3	Main boom Ien 50.4	ngth in feet 63.4	
. ,	1-				0°	21,150 (30.1)	11,600 (43.2)	5790 (56.2)	

#LMI operating code. Refer to LMI manual for instructions.

#### NOTES:

- 1. Capacities are in pounds and do not exceed 75% of tipping loads as determined by test in accordance with SAE J765.
- 2. Capacities are applicable to machines equipped with 29.5x25 (34 ply) General tires at 76 psi cold inflation pressure.
- 3. Capacities appearing above the bold line are based on structural strength and tipping should not be relied upon as a capacity limitation.
- 4. Capacities are applicable only with machine on firm level surface.
- 5. On rubber lifting with boom extensions not permitted.
- 6. For pick and carry operation, boom must be centered over front of machine, mechanical swing lock engaged and load restrained from swinging. When handling loads in the structural range with capacities close to maximum ratings, travel should be reduced to creep speeds.
- 7. Axle lockouts must be functioning when lifting on rubber.
- 8. All lifting depends on proper tire inflation, capacity and condition. Capacities must be reduced for lower tire inflation pressures. See lifting capacity chart for tire used. Damaged tires are hazardous to safe operation of crane.
- 9. Creep not over 200 ft of movement in any 30 minute period and not exceeding 1 mph.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

RELIABLE CRANE SERVICE

# 33 ft – 56 ft luffing bi-fold boom extension (Mode B) (fixed offsettable angles)

37.3 ft - 141.7 ft	33 ft - 5	) 6 ft 2	2,000 lb		00% spread	<b>Q</b> 360°			
		Pounds							
		t LENGT			-	LENGTH			
Feet	5° OFFSET #0091	20° OFFSET #0091	40° OFFSET #0091	5° OFFSET #0092	20° OFFSET #0092	40° OFFSET #0092			
40	*13,700 (78)								
45	13,700 (77)								
50	13,700 (75)	13,700 (77.5)		*8200 (78)					
55	13,700 (73.5)	13,700 (75.5)	*11,000 (78)	8200 (77.5)					
60	13,700 (71.5)	13,700 (74)	11,000 (76)	8200 (76)					
65	13,700 (70)	12,850 (72)	10,950 (74.5)	8200 (74.5)	8200 (77.5)				
70	12,500 (68)	12,000 (70)	10,350 (72.5)	8200 (73)	8200 (76)				
75	11,350 (66)	11,200 (68)	9830 (70,5)	8200 (71.5)	8100 (74)	6400 (77.5)			
80	9730 (64.5)	10,450 (66.5)	9330 (68.5)	8200 (69.5)	7600 (72.5)	6400 (76)			
85	8300 (62.5)	8980 (64.5)	8860 (66.5)	8200 (68)	7150 (71)	6230 (74)			
90	7060	7660	8210 (64.5)	7740 (66.5)	6730 (69)	5920 (72.5)			
95	5960 (58.5)	6500 (60.5)	6980 (62)	7130 (64.5)	6350 (67.5)	5640 (70.5)			
100	4990 (56.5)	5470 (58)	5880 (60)	6130 (63)	6000 (65.5)	5380 (68.5)			
105	4120 (54)	4560 (56)	4900 (58)	5230 (61)	5690 (64)	5140 (67)			
110	3340 (52)	3730 (54)	4020 (55.5)	4430 (59.5)	5290 (62)	4900 (65)			
115	2640 (49.5)	2990 (51.5)	3230 (53)	3700 (57.5)	4490 (60)	4690 (63)			
120	2000 (47.5)	2320 (49)	2510 (50.5)	3040 (55.5)	3760 (58.5)	4470 (61)			
125	1420 (45)	(49) 1700 (46.5)	1850 (47.5)	2440 (53.5)	3100 (56.5)	3710 (58.5)			
130	(+)	(40.5) 1140 (44)	1250 (45)	(55.5) 1900 (51.5)	2500 (54.5)	3030 (56.5)			
135		(44)	(45)	(31.3) 1390 (49.5)	1940	2390 (54)			
140				(49.3)	(52) 1420 (50)	(54) 1810 (52)			
145					(00)	(32) 1270 (49)			
Minimum boom (°) for indicated length (no load)	42	43	43	48	48	47			
Maximum boom (ft) at 0° boom a (no load)	n length	89.8			76.7				

NOTE: () Boom angles are in degrees. A6-829-103522 #I MI operating code. Refer to I MI manual for operating instructions

#LMI operating code. Refer to LMI manual for operating instructions. \*This capacity is based upon maximum boom angle.

### NOTES:

- 1. All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- The 33 ft luffing folding boom extension may be used for single or double line lifting service. The 56 ft luffing folding boom extension may be used for single line lifting service only. WARNING: Lifting with the 33 ft extension base, with the 23 ft extension fly either erected or folded along side of extension base, is strictly prohibited.
- WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- 4. Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- 5. Capacities listed are with outriggers properly extended and vertical jacks set only.
- 6. For main boom lengths less than 141.7 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use rating of the next lower boom angle.
- When lifting over the main boom nose with 33 ft or 56 ft extension erected, the outriggers must be fully extended or 50% extended (17.3 ft spread).

Grove RT890E

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

RT890E The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

# **33 ft – 56 ft luffing bi-fold boom extension** (Mode B) (intermediate offsettable angles)

37.3 ft - 141.	7 ft 33 ft - !	56 ft 22,000 ll	24 ft spr				
		Pou	nds				
	-	ENGTH	-	LENGTH			
Feet	5° - 20° OFFSET #0	20° - 40° OFFSET 091	5° - 20° OFFSET #0	20° - 40° OFFSET 092			
50	11,850						
55	11,550	10,750					
60	11,200	10,600					
65	10,900	10,450	6150				
70	10,650	10,350	5960				
75	10,350	9830	5780	5370			
80	9730	9330	5610	5280			
85	8300	8860	5450	5200			
90	7060	7660	5310	5130			
95	5960	6500	5170	5070			
100	4990	5470	5040	5010			
105	4120	4560	4920	4910			
110	3340	3730	4430	4810			
115	2640	2990	3700	4490			
120	2000	2320	3040	3760			
125	1420	1700	2440	3100			
130		1140	1900	2500			
135			1390	1940			
140				1420			
Min. boom angle for indicated length (no load)	43°	43°	48°	48°			
Max. boom length at 5° boom angle (no load)	89.	8'	76.	7'			

#LMI operating code. Refer to LMI manual for A6-829-103525A operating instructions.

#### NOTES:

- All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- The 33 ft luffing folding boom extension may be used for single or double line lifting service. The 56 ft luffing folding boom extension may be used for single line lifting service only.

WARNING: Lifting with the 33 ft extension base, with the 23 ft extension fly either erected or folded along side of extension base, is strictly prohibited.

- WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- 4. The loads for luffing depend on the angle of the main boom, angle of the boom extension and dynamic working pressure of the luffing cylinder for the boom extension.
- 5. Capacities listed are with outriggers properly extended and vertical jacks set only.
- When lifting over the main boom nose with 33 ft or 56 ft extension erected, the outriggers must be fully extended or 50% extended (17.3 ft spread).

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

RELIABLE CRANE SERVICE

## 33 ft - 56 ft luffing bifold boom extension with inserts (Mode B) (intermediate offsettable angles)

	<b>NIFER</b>	Ø	À [		┣━	Q
37.3 ft - 141.7 f	t 33 ft - 56 (	t 1 or 16 ft ins		000 lb 24	100% I ft sprea	360° id
(	Pounds					
	72 ft (56 ft LENGTH + 1 INSERT) 88 ft (56 ft LENGTH + 2 II					2 INSERTS)
Feet	#0095	20° OFFSET #0095	40° OFFSET #0095	5° OFFSET #1095	20° OFFSET #1095	40° OFFSET #1095
55	*6400 (78)					
60	6400 (77.5)					
65	6400 (76)			*5000 (78)		
70	6400 (74.5)	*6400 (78)		5000 (77)		
75	6400 (73.5)	6400 (76.5)		5000 (75.5)	*5000 (78)	
80	6400 (72)	6400 (75)	*5500 (78)	5000 (74.5)	5000 (76)	
85	6400 (70,5)	6040 (73.5)	5420 (76)	5000 (73)	5000 (74.5)	*4460 (78)
90	6250 (69)	5630 (72)	5100 (74.5)	5000 (71.5)	4790 (73)	4460 (76.5)
95	5800 (67.5)	5260 (70.5)	4800 (73)	4740 (70)	4420 (71.5)	4150 (75)
100	5380 (66)	4910 (69)	4520 (71.5)	4350 (69)	4090 (70.5)	3860 (73.5)
105	5010 (64)	4610 (67.5)	4270 (69.5)	4010 (67.5)	3790 (69)	3600 (72)
110	4570 (62.5)	4310 (65.5)	4020 (68)	3680	3490 (67.5)	3340 (70,5)
115	3840 (61)	4040 (64)	3790 (66)	3390 (64.5)	3230 (66)	3110 (69)
120	3180 (59.5)	3780 (62.5)	3570 (64.5)	3110 (63)	2980 (64.5)	2890 (67.5)
125	2570 (57.5)	3290 (60.5)	3370 (62.5)	2720 (61.5)	2760 (63)	2680 (66)
130	2020 (56)	2680 (59)	3180 (60.5)	2160 (60)	2540 (61.5)	2480 (64.5)
135	1510 (54)	2120 (57)	2680 (59)	1640 (58.5)	2300 (59.5)	2300 (62.5)
140	1040 (52.5)	1600 (55)	2100 (57)	1170 (57)	1780 (58)	2120 (61)
145	,,	1130 (53)	1560 (54.5)		1300 (56.5)	1820 (59)
150			1060 (52.5)			1320 (57)
Minimum bc (°) for indicat length (no lo	ed 51	52	51	56	55	56
Maximum bo (ft) at 0° boo (no load	m anglé	76.7			63.7	

NOTE: () Boom angles are in degrees. A6-829-103523 #LMI operating code. Refer to LMI manual for operating instructions. \*This capacity is based upon maximum boom angle.

#### NOTES:

- All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- 2. The 56 ft luffing folding boom extension may be used for single line lifting service only.
- WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- 4. WARNING: Lifting with the 33 ft extension base, with the 23 ft extension fly either erected or folded along side of extension base, or with either one or two 16 ft insert sections installed, is strictly prohibited.
- 5. For main boom lengths less than 141.7 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use rating of the next lower boom angle.
- When lifting over the main boom nose with the 56 ft extension erected and inserts, the outriggers must be fully extended and vertical jacks set.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

Grove RT890E The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

## 33 ft – 56 ft luffing bi-fold boom extension with inserts (Mode B) (intermediate offsettable angles)

<b>37.3 ft - 141.7 f</b>	ستر المراجع (t 33 ft - 56 f	t 1 or 2 22, 16 ft inserts		<b>A</b> 00% 360° t spread	
(	Pounds				
Feet	72 ft LENGTH ( 5° - 20° OFFSET #00	56 ft + 1 INSERT) 20° - 40° OFFSET 995	5° - 20°	56 ft + 2 INSERTS) 20° - 40° OFFSET 095	
70	6090				
75	5920		5000		
80	5750	5340	5000		
85	5600	5260	5000	4460	
90	5460	5100	4790	4460	
95	5260	4800	4420	4150	
100	4910	4520	4090	3860	
105	4610	4270	3790	3600	
110	4310	4020	3490	3340	
115	3840	3790	3230	3110	
120	3180	3570	2980	2890	
125	2570	3290	2720	2680	
130	2020	2680	2160	2480	
135	1510	2120	1640	2300	
140	1040	1600	1170	1780	
145		1130		1300	
Min. boom angle for indicated length (no load)	52°	52°	56°	56°	
Max. boom length at 5° boom angle (no load)	76.7		63.	7'	

A6-829-103526

#LMI operating code. Refer to LMI manual for operating instructions.

### NOTES:

- All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- 2. The 56 ft luffing folding boom extension may be used for single line lifting service only WARNING: Lifting with the 33
- ft extension base, with the 23 ft extension fly either erected or folded along side of extension base, or with either one or two 16 ft insert sections installed, is strictly prohibited.
- WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- The loads for luffing depend on the angle of the main boom, angle of the boom extension and dynamic working pressure of the luffing cylinder for the boom extension.
- When lifting over the main boom nose with 56 ft extension erected and inserts, the outriggers must be fully extended and vertical jacks set only.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

# Load handling

AND STREET, and show that a set of the second street of the second stree	for load handling devices
Weight regulations	

33 ft – 56 ft Folding boom extension				
*33 ft extension (erected)	3750 lb			
*56 ft extension (erected)	8000 lb			
*72 ft (1 insert erected)	10,450 lb			
*88 ft (2 inserts erected)	13,000 lb			
*Reduction of main boom capacities				
(no deduct required for stowed boom extension)				

Auxiliary boom nose	133 lb		
Hookblocks and headache balls:			
80 USt, 5 sheave	1600 lb +		
90 USt, 5 sheave	1300 lb +		
10 USt overhaul ball	568 lb +		
Defende active alete for extra local she			


+ Refer to rating plate for actual weight.

When lifting over swingaway and/or jib combinations, deduct total weight of all load handling devices reeved over main boom nose directly from swingaway or jib capacity.

NOTE: All load handling devices and boom attachments are considered part of the load and suitable allowances MUST BE MADE for their combined weights. Weights are for Grove furnished equipment.

Line pulls and reeving information				
Hoists	Cable specs	Permissible line pulls	Nominal cable length	
Main	19 mm (3/4 in) 6x37 class, EIPS, IWRC special flexible min. breaking str. 58,800 lb		600 ft	
	19 mm (3/4 in) Flex-X 35 l Aux. rotation resistant (non-rotating) nin. breaking strength 85,800	16,800 lb ) lb	600 ft	
The approximate weight of 3/4 in wire rope is 1.5 lb/ft				

The approximate weight of 3/4 in wire rope is 1.5 lb/ft



### Installation and removal of counterweight and auxiliary hoist

Rated lifting capacities in pounds on outriggers fully extended -

Radius i feet	Main boom length
	37.3 ft*
10	24,000
12	24,000
15	24,000
20	24,000
25	24,000
30	24,000
	*The boom must be fully retracted


The boom must be fully retracted.

A6-829-103450

Hoist performance					
Wire rope layer	Hoist line pulls two speed hoist Low High Available lb° Available lb°		Drum rope capacity (ft) 15 in drum Layer Total		
1	20,250	9610		101	101
2	18,490	8770		110	211
3	17,010	8070		120	331
4	15,750	7470		129	460
5	14,660	6960		139	599
	20 A 11 C 1	c 27 25 -		10.000	

\*Max. lifting capacity: 6x37 or 35x7 class = 16,800 lb

### Working area diagram



Bold lines determine the limiting position of any load for operation within working areas indicated.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

Grove RT890E The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

R

# Notes



Grove RT890E



Grove Manitowoc National Crane Potain

## **Manitowoc Cranes**

### **Regional headquarters**

#### Americas

**Manitowoc, Wisconsin, USA** Tel: +1 920 684 6621 Fax: +1 920 683 6277

### **Shady Grove, Pennsylvania, USA** Tel: +1717 597 8121 Fax: +1717 597 4062

#### **Ecully, France** Tel: +33 (0)4 72 18 20 20

Europe, Middle East, Africa

Fax: +33 (0)4 72 18 20 20 Fax: +33 (0)4 72 18 20 00

#### **China Shanghai, China** Tel: +86 21 6457 0066 Fax: +86 21 6457 4955

#### **Greater Asia-Pacific Singapore** Tel: +65 6264 1188 Fax: +65 6862 4040

## **Regional offices**

### Americas

Brazil Alphaville Mexico Monterrey Chile Santiago

### Europe, Middle East, Africa

**Czech Republic** Netvorice France Baudemont Cergy Decines Germany Langenfeld Hungary Budapest Italy Lainate Netherlands Breda Poland Warsaw Portugal Baltar Russia Moscow U.A.E. Dubai U.K. Buckingham

**China** Beijing Chengdu Guangzhou Xian

### **Greater Asia-Pacific**

Australia Adelaide Brisbane Melbourne Sydney India Calcutta Chennai Delhi Hyderabad Pune Korea Seoul Philippines Makati City Singapore

Zhangjiagang France Charlieu Moulins Germany Wilhelmshaven India Pune Italy Niella Tanaro Portugal Baltar Fânzeres Slovakia Saris USA Manitowoc Port Washington Shady Grove

Factories

Brazil

China

TaiAn

Alphaville

This document is non-contractual. Constant improvement and engineering progress make it necessary that we reserve the right to make specification, equipment, and price changes without notice. Illustrations shown may include optional equipment and accessories and may not include all standard equipment.

©2011 Manitowoc Printed in USA Form No. RT890E PG Part No. 04-008 - 2M -1211

www.manitowoc.com